

BEFORE RETURN

1 CLEAN THE SHOWER

for proper cleaning - visit below address and watch our videos
<https://www.fawssit.com/temporary-shower-stall-resources/>



or scan this QR

2

MAKE SURE THE SHOWER IS CORRECTLY PREPARED FOR BOXING

Properly secure the water pan to the frame

Roll up the hose and fold down the shower head on the inside panel

Spool & secure waste water hose and power cord on the outside of the folded frame



BOXING INSTRUCTIONS



You will need:

- original box
- original foam corners
- packaging tape



3 Position the cleaned and folded shower in front of the open box
(pump side goes in last)



4 Insert the folded shower legs into **wider** foam corner
(the 3 other corners have a narrower opening)



5 Place second foam corner on the top of the folded shower



Slide the shower in - it helps greatly to have a second person to help or do this with the box against a wall



Place remaining foam corners over the bottom



and top of the shower



Push the shower completely into the box



Flip the box for the open side to be on top



Finish by taping the box shut